

[Print](#)
[Close This Window](#)

Welcome to the Koss Cobalt™ Wireless Stereophone. Your new stereophone includes the following features:

- Frequency Response: 20 - 22,000 Hz
- Wireless communication
- Approximately 33 foot range
- Transmits through walls and ceilings
- Compatible with select mobile phones
- Rechargeable internal Lithium-ion battery
- Up to 8 hours of battery life

Includes:

- Koss Cobalt™ Wireless Stereophone.
- Audio Transmitter
- USB Audio Dongle
- USB charging cable
- AC charging adapter
- Audio extension cable

USING THE KOSS COBALT™ FOR THE FIRST TIME:

Charging the unit:

It is recommended that you fully charge your stereophone before use. To charge your stereophone, follow these instructions:

1. Plug the small end of the USB charging cable into the charging jack on the stereophone, and the other end into your computer, OR plug the AC adapter into the charging jack on the stereophone, and the other end into a wall outlet.
2. The charging LED will illuminate RED while charging .
3. When a charge is complete, the RED charging LED will turn off.

Connecting the Audio Transmitter to your audio player:

Simply insert the 3.5mm plug on the Audio Transmitter into the 3.5mm jack on your audio player. If the plug does not completely insert in the jack, use the included audio extension cable to connect the Transmitter.

Connecting the USB Audio Dongle to your Windows® PC*:

When you first connect the USB Audio Dongle to your PC, it will be automatically recognized by Windows®.

1. Insert the USB Audio Dongle into a free USB port on your PC.
2. The “Found New Hardware” message will be displayed on your screen. After the installation process is complete, the message “Your new hardware is installed and ready to use” will appear.
3. To check that your PC’s audio is being routed to the USB Audio Dongle, double-click the

speaker icon in your Windows® system tray. “Audio Dongle” should appear in the lower left corner.

*instructions for Windows® XP, 2000, and ME. USB drivers are required for Windows® 98, and are available from Microsoft®

KOSS COBALT™ GENERAL USAGE INSTRUCTIONS:

Using the stereophone with the Audio Transmitter:

In order for the Koss Cobalt™ stereophone to communicate with the Audio Transmitter, the units must be “paired.” Only one (1) transmitter may be paired with the stereophone at a time. Follow these steps for pairing the stereophone to the Audio Transmitter:

1. Turn the switch on the Audio Transmitter to the “ON” position. The LED on the back of the Transmitter will illuminate.
2. Hold the On / Off/ End Call button on the stereophone for 5 seconds. You will hear the “ON” tone through the stereophone.
3. The stereophone will immediately begin searching for wireless devices, and the connection LED will illuminate intermittently.
4. When a connection has been established (can take up to 60 seconds), both the LED on the transmitter and the connection LED on the stereophone will flash twice every 3 seconds, for as long as they are paired.
5. You may now press “Play” on your audio player.

Using the stereophone with the USB Audio Dongle:

In order for the Cobalt™ stereophone to communicate with the USB Audio Dongle, the units must be “paired.” Only one (1) dongle may be paired with the stereophone at a time. Follow these steps for pairing the stereophone to the USB Audio Dongle:

1. Check that the LED on the USB Audio Dongle is illuminated.
2. Hold the On/Off/End Call button on the stereophone for 5 seconds. You will hear the “ON” tone through the stereophone.
3. The stereophone will immediately begin searching for wireless devices, and the connection LED will illuminate intermittently.
4. When a connection has been established (can take up to 60 seconds), both the LED on the USB Audio Dongle and the connection LED on the stereophone will flash twice every 3 seconds, for as long as they are paired.
5. All sound from your computer will now be played through the stereophone. You can control playback of your media player application by using the Play/Pause/Answer button.

Using with your mobile phone:

The Koss Cobalt™ can be used with select mobile phones. To pair with your mobile phone, follow these instructions:

1. Enable Bluetooth® on your phone (refer to the phone’s user manual). Turn on the stereophone. Check that no other device connects with the headset by confirming that the connection LED is not flashing.
2. In the phone’s menu, search for devices.
3. Select KBT1 Headset.

4. Enter the PIN code “0000”.

Answering calls:

To answer a call, press the Play/Pause/Answer button. To end a call, push the On/Off/End button.

Turning off the stereophone:

To turn off the stereophone, hold the On/Off/End Call button for 3 seconds. The connection LED will blink 3 times and the unit will power down.

TROUBLESHOOTING:

No audio output with illuminated connection LED (not paired): Check status of Transmitter or Dongle. Make sure stereophone is within transmission range. Turn off all devices and turn them back on in order listed in this guide.

No audio output with blinking LED (paired): Check volume level of stereophone, as well as volume levels on your computer/player. Ensure that your computer’s audio settings are configured for the Dongle.

Stereophone cannot be turned off: Reset the stereophone using the reset button. The reset button is located on the top of the left earcup. Simply insert a paper clip into the hole to reset the unit.

Sound can be heard but music is not audible (computer): Close and re-open your media player software.

If you need further information, please contact our Consumer Sales Department at 1-800-USA-KOSS.